

Nondestructive Evaluation Sciences Branch


Comparison of In-situ Near Infrared Melt Pool Imagery to Optical Microscopy Measurements

Joseph N. Zalameda,

Samuel J. A. Hocker, Joshua M. Fody, Wesley A.
Tayon, and Brodan Richter

NASA Langley Research Center

SPIE Thermosense Conference April 3 -7, 2022





Outline

- Introduction/Motivation
- Configurable Architecture Additive Testbed (CAAT)
 - Overall Description for Selective Laser Melting
 - Calibration of Near Infrared (NIR) Camera
- Measurement Results
 - Melt Pool Imaging on Ti-6Al-4V Plate
 - Comparison to Optical Microscopy
- Conclusions
- Future Work



NASA Transformational Tools and Technologies Project – Additive Manufacturing (Metals)





Introduction


Nondestructive Evaluation Sciences Branch

Objectives

- Investigate the use of a low cost in-situ near infrared (NIR) sensor for real time measurement of the thermal history for improved additive manufactured builds.
- Calibrate the NIR sensor and investigate the measured melt pool size based on varying process parameters.
- Compare the melt pool width with microscopy measurements.



Payoffs


- Additively manufactured parts must be certified for broad application onto aircraft structures. By documenting the thermal history, process parameters for microstructure can be evaluated and real time inspections can be performed during the AM build. These results can be used to validate thermal models and build process parameters.



Configurable Architecture Additive Testbed (CAAT)


Nondestructive Evaluation Sciences Branch






Co-axial NIR Optical Path


Nondestructive Evaluation Sciences Branch



Basler acA640-750um




- NIR camera has 640 x 480 FPA, maximum frame rate = 751 Hz, pixel pitch is 4.8 x 4.8 μm , configured with focusing optics and 880 nm narrow bandpass filter (875-884nm), resolution approximately 8.55 microns, ROI for images 144 x 144, and provides frame rate of approximately 2,000 Hz.




Effective Radiance

Nondestructive Evaluation Sciences Branch

$$Radiance = \frac{1}{2} \int_{\lambda_1}^{\lambda_2} \frac{\frac{c_1}{c_2}}{\lambda^5 (e^{\frac{h * c}{k * \lambda * (T + 273.15)}} - 1)} * sensor(\lambda) * filter(\lambda) * d\lambda \quad \text{where } c_1 = 2 * h * c^2 \quad \text{and} \quad c_2 =$$




- Spectral band 875 to 884 nm defined by the 880 nm narrow bandpass filter.



Calibration of NIR Camera

Nondestructive Evaluation Sciences Branch




NIR
Camera




Basler acA640-750um

- Blackbody radiation source placed within build chamber for direct view.
- Temperatures used were 900, 1000, 1100, 1200, 1300, 1400, and 1500 degrees C.
- Integration times were varied 59, 75, 100, 150, 300, 500, 700, 900, 1200, and 1500 micro-seconds.
- Camera gain was set to 0 db.
- NIR camera was configured with 880 nm band pass filter.
- Camera frame rate approximately 2,000. Hertz with ROI pixel array size of 144x144.





NIR Camera Calibration Results from Blackbody Radiation Source

NIR Camera Response





Calibration Equation from Fit






In-situ NIR Melt Pool Imaging Results

Nondestructive Evaluation Sciences Branch






Requirements for Measurement of Melt Pool Width

Nondestructive Evaluation Sciences Branch


- Thermal camera pixel resolution – Measured Pixel Resolution Approximately 8.55 microns.
- Solidus temperature value – 1605 Degrees C (Ti-6Al-4V).
- Blurring due to movement of laser beam vs. camera integration time.
- Surface emissivity value (vary with material, surface geometry and temperature).
- Accurate destructive measurements using microscopy.



Melt Pool Imagery (Laser Scanning 500 mm/sec) for Various Emissivity Values Compared to Optical Microscopy – Blurring Uncorrected


Nondestructive Evaluation Sciences Branch


Top Down Image



Laser Scanning
Direction →


Laser Velocity =
500 mm/sec






Melt Pool Imagery (Laser Scanning 750 mm/sec) for Various Emissivity Values Compared to Optical Microscopy – Blurring Uncorrected

Nondestructive Evaluation Sciences Branch







Removal of Blurring using Inverse Filtering


Nondestructive Evaluation Sciences Branch

- Laser velocity of 500 and 750 mm/sec combined with camera integration time (200 microseconds) results in ~ 12 pixel and ~ 18 pixel blur respectively.
- Use Weiner inverse filtering technique to remove camera blur.

$$W(u, v) = \frac{H^*(u, v)}{|H(u, v)|^2 + K(u, v)}$$


$$\text{Deblurred Image}(u, v) = W(u, v) \text{Blurred Image}(u, v)$$






Melt Pool Imagery (Laser Scanning 500 mm/sec) for Various Emissivity Values Compared to Optical Microscopy – Blurring Corrected


Nondestructive Evaluation Sciences Branch






Melt Pool Imagery (Laser Scanning 750 mm/sec) for Various Emissivity Values Compared to Optical Microscopy – Blurring Corrected

Nondestructive Evaluation Sciences Branch







Nondestructive Evaluation Sciences Branch

Optical Microscopy Measurement Challenges for Melt Pool Width


Melt Pool Width
by Cross Section





Conclusions

- A low cost NIR camera was calibrated and used to measure the width of the melt pool on a Ti-6Al-4V plate.
- Blurring effects, due to relatively long integration time, was reduced by inverse filtering.
- Optical microscopy measurements were used to compare the NIR melt pool width with marginal agreement. Need to investigate error in optical microscopy measurements to validate NIR melt pool width measurements.



Future Efforts

Nondestructive Evaluation Sciences Branch

- Higher speed cameras will be used for improved temporal and spatial imaging.
- Investigate pyrometry imaging techniques for emissivity corrected temperature measurements.
- Comparison of melt pool width measurements to FEM models for given process parameters is desired.



Photron Nova S6

